


FlexiSpot

Item No. C7

User Manual



Warranty



+49 211 368 74223
info@flexispot.de

CONTENTS

English-----01

German-----07

French-----13

Italian-----19

Spanish-----25


PARTS

A	B	Cx5	D	I x4+1 (M8*40MM)
E	F	G	H	J x1+1 (M6*30MM)
				K x6+1 (M6*30MM)
				L x3+1 (M8*20MM)
				Mx1


Assembly Instructions

Before assembling this product, please read these instructions carefully.


1




2




3




4




5






6



7



8



Attention: If you find the lumbar support too firm, you can choose to put the cover on it. Please be careful not to hurt your hands when doing this.











Diagram of Adjustment



Safety Instructions

WARNING: Failing to follow the instructions below may result in serious injury!

1. This product is for sitting only, it is strictly forbidden to stand on the product or to use it as a ladder, etc;
2. Use this product only when all screws and parts are locked. Check the locking of all screws and parts at least every 3 months;
3. If any parts are missing, damaged, or worn, stop using the product and repair it with factory-supplied parts;
4. It is strictly forbidden to sit on the armrests of the product;
5. This product is designed as a one-person seat and is limited to one person per use;
6. Children under the age of 10 should use this product under adult supervision.